



## UNIDAD DE RELÉ R-3

R-3 RELAY UNIT



## UNIDAD DE RELÉ SAR-90

SAR-90 RELAY UNIT



+(34) 934 800 696

+(34) 609 807 631

golmar@golmar.es

T190

rev.0102

Sonerías adicionales  
y unidades de relé

*Auxiliary calling  
and relay units*

manual de instalación  
*instructions manual*

## MODELOS Y APLICACIÓN

MODELS AND SCOPE

### Sonerías auxiliares

*Auxiliary calling units*

S-4	T-810, T-810R, T-910, T-910R
S-8	Xic-90, T-800, T-900
SAV-90	T-840, T-940 Plus, Shiner-90, Shiner Plus


### Unidades de relé

*Relay units*

R-3	T-810, T-810R, T-910, T-910R
SAR-90	T-840, T-940 Plus, Shiner-90, Shiner Plus


## SONERÍA AUXILIAR S-4

S-4 AUXILIARY CALLING UNIT



## SONERÍA AUXILIAR S-8


S-8 AUXILIARY CALLING UNIT




## SONERÍA AUXILIAR SAV-90

SAV-90 AUXILIARY CALLING UNIT


Selección del volumen de llamada mediante CN2.  
*Setting the call volume with CN2 jumper.*



Máximo/Maximum.



Medio/Medium.



Mínimo/Minimum.

